

A gauge drops fast when a brand-new system should be holding steady.

That's the moment your stomach sinks. Not because the condenser is bad. Not because the evaporator is undersized. Because a simple measuring mistake on the **line set** turned into a leak, an oil return problem, or a pressure drop nobody caught until startup.

Here's the part most installers learn the hard way: a **refrigerant line set** that's off by even a few feet can trigger extra fittings, ugly bends, insulation gaps, and charge adjustments that eat your margin alive. On long runs, the wrong measurement can cost more than the copper itself. On short runs, it can force loops and traps you never wanted. And yes, I've seen a bad measurement create a callback that landed at \$438 after labor, refrigerant, and a second truck roll.

A few months ago, I got a call from **Leandro Velez**, a 41-year-old ductless installer in Boise, Idaho, who was roughing in a **24,000 BTU mini split line set** on a sun-beaten bonus-room addition. He'd already been burned by a **Diversitech** set whose foam separated at the first bend, leaving condensation marks down fresh drywall. This time, he wanted the measurement right before he ordered anything. Smart move. Because once you know how to measure an **ac unit line set** correctly, the whole install goes smoother—routing, flaring, evacuation, charging, and the final look of the job.

And if you're ordering materials instead of grabbing whatever's on a local shelf, it helps to compare **pre-insulated line sets** by copper grade, insulation quality, and capped-end protection rather than price alone. A rushed buy usually shows up later as moisture contamination, UV-cracked foam, or another afternoon spent fixing something that should've lasted 10 years.

This guide breaks the job into seven field-practical steps.

Measure the route. Account for bends. Match the equipment. Plan for the real-world install. And avoid the little mistakes that create the expensive ones.

#1. Start With the Actual Route — Measure the Installed Path, Not the Straight-Line Distance

A proper **air conditioning line set** measurement is the total installed path from the outdoor service valves to the indoor coil or evaporator connection, including every vertical rise, horizontal run, and turning allowance. If you measure wall-to-wall in a straight line, you're not measuring the job—you're measuring a fantasy.

That's where good installs go bad.

Leandro learned that on a second-floor ductless project where the direct distance looked like 18 feet, but the finished route needed 26 feet once the wall penetration, line-hide turns, and condenser offset were included. That eight-foot miss would've forced a splice or a full reorder.

Find the true start and end points

Start at the **service valve** connection on the outdoor unit, not the edge of the pad. End at the actual indoor flare or braze connection, not the center of the air handler. That distinction matters because many systems hide 12 to 24 inches of connection space behind equipment cabinets and covers.

If you're measuring a **line set for AC unit** installation on a **wall-mounted evaporator**, account for the internal stub-out location. On a central split system, measure to the **coil cabinet** connection point. A tape that starts and

stops at visible equipment edges almost always comes up short.

Follow the route your tubing will really take

Run your tape along framing, line-hide, joists, chases, or exterior wall surfaces exactly where the **copper line set** will be secured. Don't measure through open air. **HVAC copper tubing** doesn't teleport across corners.

What size line set do I need for a mini-split system? You need the line diameters specified by the equipment manufacturer—commonly **1/4" liquid line** with **3/8" suction line** for **9,000 to 12,000 BTU** units, and often **3/8" liquid** with **5/8" suction** for **18,000 to 24,000 BTU** systems. The measurement step comes after diameter is confirmed, because the right length of the wrong size is still the wrong order.

Write down each segment separately

Break the run into segments: pad to wall, wall rise, attic crossing, drop, and final equipment connection. That makes it easier to catch missed footage and helps if you're comparing a **15 ft line set**, **25 ft line set**, **35 ft line set**, or **50 ft line set**.

I've found segment measuring cuts ordering mistakes sharply because your eye stops guessing. And guessing is what gets you the callback.

#2. Add Bends, Slack, and Serviceability — Real Installs Need Working Room

A measured route is not the same thing as an order length. A usable **hvac line set** needs allowance for bending radius, vibration separation, connection access, and a clean service loop where required.

This is the step many people skip.

It's also where the cleanest installs are won.

A bare-minimum cut might technically reach. But if you can't pull the flare square, isolate vibration, or remove a panel later, you didn't [line set](#) really save anything.

Add bend allowance instead of forcing tight turns

Every 90-degree turn eats length. Depending on tubing size and bend radius, I typically allow 8 to 14 inches per major turn on ductless work and sometimes more on larger **suction line** sizes. Trying to "save copper" by pulling hard corners often kinks the tube or pulls the insulation away at the bend.

Why does line set insulation separate from the copper tubing? It usually happens when the foam isn't factory-bonded well or when the installer forces a bend tighter than the tubing and insulation can tolerate. Once that gap opens, condensation starts showing up exactly where you don't want it.

Leave enough line for service access

You want enough extra length at both ends to make a proper flare, braze comfortably, pressure test, and service the unit later without straining the connection. On mini-splits, that often means at least 12 to 18 inches of workable line at the indoor end before trimming.

Leandro now adds a written "service allowance" to every measurement sheet because he got tired of watching perfect rough measurements turn into awkward finish work. It sounds small. It saves jobs.

Respect manufacturer minimum and maximum lengths

Some systems require a minimum line length for proper noise control or oil return, while long runs may require additional **refrigerant charge**. Many manufacturers list charge adjustments by ounce per foot beyond a standard allowance, often after 15 feet or 25 feet.

That's why "close enough" doesn't belong in **AC refrigerant lines**. A line run that is 11 feet in the field but cut to 8 feet because someone ignored routing and slack can create a lot more trouble than it saves.

#3. Match Length to System Design — Size, Capacity, and Refrigerant Rules Come First

Measuring a line set correctly means confirming that the run length works with the equipment's required diameters, lift limits, and total equivalent length. Length and size are married; you don't get to treat them like separate decisions.

And this is where a lot of online advice falls apart.

A **mini split line set** for a **12,000 BTU** inverter system has different needs than a **3-ton system** in a split attic install. The tape measure only tells you distance. The equipment data tells you whether that distance is acceptable.

Use the nameplate and installation manual, not memory

Most installers remember common pairings, but memory is not a spec sheet. Verify **BTU rating**, approved line diameters, maximum lift, and total run. For example, many 12k ductless systems use **1/4" x 3/8"**, while some **24,000 BTU** equipment uses **3/8" x 5/8"**.

Can I use the same line set for **R-410A refrigerant** and **R-32 refrigerant**? In many cases, yes, if the tubing meets the pressure and material requirements in the manufacturer literature, especially **ASTM B280** standards. But the answer is always system-specific, and future-proofing matters more now than it did five years ago.

Longer runs change performance

Long lines affect **pressure drop**, **subcooling**, oil return, and total system efficiency. A sloppy estimate can move you from a standard charge to an adjusted charge, which means more refrigerant, more labor, and more time on startup.

Here's a field rule worth remembering: once line routing starts pushing the upper half of an equipment's allowed run, accuracy stops being a convenience and becomes system protection.

Professional-grade compatibility matters more than people think

On **Daikin**, **Mitsubishi Electric**, and **Carrier** jobs, I've seen installers get obsessive about inverter boards and startup procedures while treating the tubing as an afterthought. That's backwards. **Mueller Line Sets** sold through **PSAM** use Made in USA **Type L copper**, come **factory pre-insulated** with **DuraGuard black oxide**, and are built for licensed HVAC techs and capable homeowners.

When a line run is near the manufacturer's upper limit, domestic copper consistency matters. **Compared to Diversitech**, whose foam can separate during aggressive bends, and **generic import brands** that often show **8–12% wall-thickness variation**, a premium domestic assembly gives you a lot more confidence in the field. That variation sounds small until you're making flares or checking for uneven seating at startup. In real jobs, pre-insulated domestic assemblies also remove **45 to 60 minutes** of field wrapping, which is why many contractors

recover **\$75 to \$120** per installation in labor alone. That's before you count a single avoided callback. On longer exterior runs with full sun exposure, better insulation adhesion and cleaner tolerances aren't luxuries. They're worth every single penny.

#4. Measure Vertical Rise and Line-Hide Routing — The Wall Is Usually Hiding Extra Feet

Vertical rise is the footage installers undercount most often. It looks simple from the ground. Then you open the chase, hit a header, dodge a soffit, and suddenly your 22-foot **ac lineset** is a 31-footer.

This is especially true on ductless retrofits.

Leandro's Boise project looked like a tidy one-story exterior drop until the line-hide needed a wider sweep around a window trim stack and a deeper turn into the indoor head. That added nearly 5 feet by itself.

Count every rise and drop from finished connection points

Measure vertical distance from actual connection points, not from the floor or pad surface. If your outdoor unit sits on a stand or wall bracket, include that elevation. If your indoor unit connections are offset inside the cabinet, include that too.

I've seen installers miss 18 inches at the condenser and another 14 inches at the head. That's over 2.5 feet lost before the first bend.

Line-hide systems increase equivalent run length

Exterior covers clean up the install, but they usually require wider directional changes than exposed tubing. That means more bend allowance and sometimes more service slack. Measure the route as if the cover is already installed.

What is the difference between pre-insulated and field-wrapped line sets? A factory **pre-insulated line set** arrives with consistent foam thickness and vapor protection already bonded to the tubing. Field wrap can work, but it often adds labor, creates uneven seams, and leaves weak points at transitions and bends.

Don't forget penetration depth and interior turning space

Wall thickness, sleeve depth, and the first interior bend count. So do attic offsets and framing detours. On renovations, these hidden inches are the ones that force a coupling when the line just barely misses.

And "barely" is an expensive word in this trade.

#5. Use an Installation Decision Framework — Six Checks Before You Order Any Line Set

A line set buying decision should be based on measurable construction standards, not packaging claims or price tags. If you evaluate six core criteria in the right order, you can usually predict which products will install cleanly and which ones will come back as headaches.

Here's the framework I'd use before any order.

1. Copper origin and construction grade

Look for **Type L copper tubing** built to **ASTM B280**. That standard matters because refrigerant tubing isn't plumbing scrap with insulation thrown over it. Domestic Type L assemblies are valued in the field because tighter wall consistency supports better flares, fewer weak spots, and more predictable pressure performance.

2. Insulation R-value and adhesion method

The foam should be closed-cell and clearly rated, ideally above **R-4.0**. If the insulation slips on the first bend or opens at the seam, expect condensation trouble. Better assemblies hold the foam to the tube through handling and installation.

3. UV and weather resistance coating

Outdoor runs need more than white foam and hope. A **UV-resistant jacket** or durable black protective coating matters because unprotected insulation can chalk, split, or waterlog after **18 to 24 months** of direct exposure in harsh sun. Good exterior protection can extend outdoor life by about **40%**.

4. Nitrogen charging and end-cap quality

A **nitrogen-charged line set** with sealed caps keeps moisture and debris out before installation. If the caps fit loosely or the lines arrive contaminated, your vacuum process starts from behind. Clean, dry tubing is not a bonus. It's the baseline.

5. Warranty coverage and manufacturer support

Read the warranty before you buy. A meaningful benchmark is **10 years on copper** and at least **5 years on insulation**, because that tells you the manufacturer expects the assembly to survive real weather and real handling.

6. Refrigerant compatibility and future-proofing

Your **refrigerant copper tubing** should be suitable for current high-pressure systems and the ongoing transition toward newer refrigerants. If you're installing for long-term ownership, compatibility with today's **R-410A** equipment and tomorrow's alternatives matters.

Why this framework beats bargain shopping

This is where Leandro changed his ordering habit after the earlier insulation failure. He stopped comparing catalog photos and started comparing standards. **Mueller pre-insulated line sets stocked at Plumbing Supply And More use ASTM B280 copper, a DuraGuard UV-resistant finish, and are built for professional installers and DIY mini-split buyers.**

And when you compare that framework against **JMF** and **Supco**, the difference shows up fast in real work. Some lower-tier options still require extra field wrapping or show premature jacket wear on exposed runs. A line set that saves a few dollars up front but adds nearly an hour of labor—or leaves you with wet drywall a year later—isn't cheaper. It's just delayed expense. That's why well-built assemblies are worth every single penny.

#6. Plan for Connections, Tools, and Trim Length — Measuring Ends the Right Way Prevents Leaks

A finished measurement is only useful if it leaves you enough material to make a clean connection. Final trim, flaring, deburring, and torque access are part of measuring whether you admit it or not.

This is where “exact length” often becomes “not enough length.”

Measure to connection type: flare or sweat

A **flare connection** needs clean, straight tubing with enough protrusion for the block and proper tool alignment. A **sweat connection** needs room for prep, shielding, and heat control. If you trim to the shortest possible number, you leave no margin for a bad cut.



What does nitrogen-charged mean on a pre-insulated line set? It means the tubing is factory sealed with a dry nitrogen holding charge to reduce internal moisture and contamination before installation. That matters because moisture in **HVAC line set installation** is one of the fastest ways to create acid formation, poor evacuation results, and long-term compressor trouble.

Account for tool clearance and cabinet access

You need physical room for a **flaring tool**, **torque wrench**, **tube cutter**, and often a **deburring tool**. I’ve seen beautiful rough-ins become awkward nightmares because no one measured the last 6 inches with the service panel open.

Leandro now photographs every indoor and outdoor connection area before ordering so he can spot where tool clearance demands an extra foot. That one habit has saved him more than one reorder.

Trim after fit-up, not before

Dry-fit the route, then trim to final length. On mini-splits, that’s especially important because factory tails, wall sleeves, and line-hide transitions can shift your workable length by several inches.

And several inches is enough to ruin a flare.

#7. Verify Against a Final Field Checklist — The Last Five Minutes Save the Callback

A final measurement check is a short verification pass done before ordering or cutting. It confirms route length, line size, bend count, connection allowance, and exposure conditions so your **copper line set** fits the job without

compromise.

This is the last easy moment to catch the expensive mistake.

Miss it now, and you'll find it at startup—or worse, on the callback.

Use a five-point verification pass

Before you order, confirm: equipment-required diameter, total route footage, bend allowance, service slack, and outdoor exposure. If any one of those is uncertain, your number isn't final yet.

How long should refrigerant lines last on an outdoor installation? On properly supported runs using quality copper and UV-protected insulation, 10 years is a realistic baseline **copper line set** and often longer. On exposed bargain products with weak jackets, visible deterioration can start in under 24 months, especially in desert or high-UV environments.

Check climate exposure before choosing length and insulation

Exterior line runs in Boise aren't the same as coastal Florida or Phoenix rooftops. Sun, wind, and freeze-thaw cycles all affect jacket survival and support spacing. If a run is heavily exposed, choose a **pre-insulated line set** with verified weather protection instead of planning to "wrap it later."

Here's my field opinion in one sentence: when a line set gives you **R-4.2** insulation, **15% thicker** domestic copper walls, and a **10-year copper warranty**, you buy fewer callbacks, not just better tubing.

Document the final number

Write the chosen length on the job sheet with the equipment model and required line sizes. That record protects your crew, your purchasing, and your future service tech.

Leandro ended up ordering a 35-foot assembly for that 24k ductless install, even though the straight shot looked closer to 25 feet. The final route used 29 feet, left proper working room, and finished clean. More important, that project joined a run of 27 installations without a single line-related callback.

Frequently Asked Questions

How do I determine the correct line set size for my mini-split or central AC system?

Check the manufacturer's installation manual and equipment nameplate for the required liquid and suction diameters, then verify the allowed total line length and vertical lift. Common sizes are **1/4" x 3/8"** for many 9k–12k mini-splits and **3/8" x 3/4"** for some 3-ton central systems.

The key is that "size" means both diameter and length. A **mini split line set** must match compressor design, oil return requirements, and refrigerant velocity targets. Many **12,000 BTU** ductless units use **1/4" liquid** and **3/8" suction**, while **24,000 BTU** systems often step up to **3/8" liquid** and **5/8" suction**. Central split systems can run larger suction lines depending on tonnage and total equivalent length. If the route is long, you may need additional charge adjustments per foot beyond a factory allowance. Always start with the manual, then measure the installed path including bends, service loops, and vertical rise. That approach keeps **AC refrigerant lines** matched to real-world installation conditions instead of guesswork.

What is the difference between 1/4 inch and 3/8 inch liquid lines for refrigerant capacity?

A **1/4-inch** liquid line is common on smaller-capacity systems, while a **3/8-inch** liquid line is typically used on larger systems that need greater refrigerant flow. The correct choice depends on the condenser and evaporator design, not just line length.

Liquid line diameter affects pressure characteristics, charge stability, and overall system performance. On many **9,000 to 12,000 BTU** mini-splits, a **1/4" liquid line** is standard because the metering and compressor design are built around that flow rate. Larger systems, including some **18,000 to 36,000 BTU** units, may require **3/8" liquid** lines to support higher refrigerant movement without excessive pressure loss. Using the wrong diameter can alter **subcooling**, affect expansion device behavior, and reduce efficiency. It can also complicate startup diagnostics because readings no longer match expected factory conditions. The safe rule is simple: never "upgrade" or "substitute" liquid line sizes unless the equipment manufacturer explicitly allows it.

Why is domestic Type L copper superior to import copper for HVAC refrigerant lines?

Domestic **Type L copper** built to **ASTM B280** generally offers tighter wall consistency, better purity, and more reliable flaring performance than bargain import tubing. Those traits reduce the chance of pinholes, split flares, and uneven wall stress under high-pressure refrigerants.

In the field, the difference shows up during bending, flaring, and long-term reliability. A better **copper line set** tends to hold dimensional tolerances closer, often around **±2%**, while lower-grade import tubing may vary much more. That matters because high-pressure systems using **R-410A refrigerant** and newer alternatives don't forgive weak tubing. Better material also reduces the chance of hidden defects that become leaks after seasonal expansion and contraction. When contractors complain about "mystery leaks" on newer installs, tubing quality is often part of the story. With refrigerant costs and callback labor where they are now, better copper construction stops being a luxury and starts looking like basic risk control.

How does insulation quality affect condensation on a line set?

Insulation quality controls whether the suction line stays above the dew point of the surrounding air. If the foam has poor thermal resistance, loose seams, or gaps at bends, condensation forms quickly and can damage ceilings, walls, and finished surfaces.

Closed-cell insulation is preferred because it resists moisture absorption and maintains a vapor barrier more effectively than open-cell materials. A rating above **R-4.0**, such as **R-4.2**, gives better protection in humid spaces like attics, crawlspaces, and wall cavities. The other big factor is adhesion. If the insulation pulls away from the copper during installation, the exposed section sweats even if the rest of the tube is wrapped. That's why pre-insulated assemblies often outperform field-wrapped jobs: consistent thickness, cleaner seams, and fewer weak spots around turns. In humid climates, one failed bend can create enough dripping to stain drywall within a single cooling season.

Can I install a pre-insulated line set myself or do I need a licensed HVAC contractor?

A capable homeowner can physically route and support a **pre-insulated line set**, but final connection, evacuation, leak testing, and charging should usually be handled by a licensed HVAC contractor. The copper work is only part of the installation; system commissioning is where most expensive mistakes happen.

DIY installers often underestimate what comes after the tubing is hung. You still need proper cut preparation, accurate flaring, torque values, a deep vacuum, and pressure testing with dry nitrogen. You also need to confirm manufacturer requirements for line length, oil return, and any added refrigerant charge. A poor flare or

contaminated line can damage a compressor long before the problem becomes obvious. That said, factory-insulated assemblies do make rough-in easier for skilled homeowners because they remove much of the labor tied to wrapping and seam management. If you're not comfortable with **vacuum pump**, **manifold**, and leak-test procedures, bring in a pro for the final commissioning step.



What is the difference between flare connections and quick-connect fittings for mini-splits?

Flare connections use formed copper ends tightened to a specified torque, while quick-connect fittings are pre-engineered couplings designed to simplify hookup. Flare systems are more common across professional mini-split installations because they offer broader compatibility and easier serviceability.

A properly made flare can be extremely reliable, but it depends on clean tubing, correct angle formation, deburring, and torque control. Too loose and it leaks. Too tight and it cracks. Quick-connect styles reduce some skill dependency, but they can limit equipment choices and may still require careful routing and handling to avoid stress at the fitting. For most **ductless line set** jobs, flare remains the standard because it pairs well with manufacturer-supplied valves and supports easier replacement later. The important point is to measure with the connection type in mind. Flare work needs tool access and trim allowance. Quick-connect assemblies may require more routing space to avoid side-loading the fitting.

What does nitrogen-charged mean and why does it matter for line set installation?

A nitrogen-charged line set is factory sealed with dry nitrogen to keep internal surfaces clean and moisture-free before installation. That protection matters because contamination inside refrigerant tubing can increase evacuation time, create acids, and shorten compressor life.

When line sets sit in warehouses, trucks, or jobsite conditions, open ends can pull in humidity, dust, and debris. Even small moisture levels become a problem once refrigerant and oil are introduced. Dry nitrogen helps preserve the inside of the tubing until the installer cuts the caps and starts fit-up. It's not a substitute for proper evacuation, but it gives you a cleaner starting point. On long storage jobs or humid-climate installations, that can make a real difference in vacuum performance. Contractors who've opened bargain tubing and found questionable cap quality understand this immediately. Clean, sealed **refrigerant copper tubing** simply gives the rest of the commissioning process a better chance to succeed.

How long should refrigerant lines last in outdoor installations exposed to sun and weather?

Well-supported outdoor refrigerant lines made from quality copper with durable UV-protected insulation should last 10 years or more, often considerably longer. Exposed low-grade insulation can begin cracking, chalking, or waterlogging in less than 24 months under strong sunlight.

Outdoor lifespan depends on three things: copper quality, insulation design, and UV defense. In harsh sun, standard foam jackets can break down fast, especially where support straps pinch the insulation or where the first bend exposes weak adhesion. Better assemblies use closed-cell insulation plus a weather-resistant exterior finish to slow UV damage. Some products are tested to show roughly **40% longer outdoor lifespan** than standard unprotected assemblies. Support spacing matters too. Tubing that sags or rubs against masonry ages faster and becomes more vulnerable to abrasion. If the job has direct sun, rooftop exposure, or major seasonal temperature swings, choose your **air conditioning line set** like it's going to stay outdoors for a decade—because it probably will.

What maintenance tasks extend refrigerant line lifespan and prevent pinhole leaks?

Inspect support points, exposed insulation, line-hide entries, and connection areas annually. Replace damaged UV tape or jacket sections early, keep the tubing isolated from dissimilar metals, and address vibration or rubbing before it wears through copper or insulation.

Most line failures don't begin in the middle of a straight run. They start at stress points: clamp locations, bends, wall penetrations, or flare connections. A yearly visual check can catch abrasion, oil staining, jacket cracking, and insulation separation before they become leaks. In coastal or industrial environments, surface contamination should be cleaned off exposed protective jackets, and any missing sealant at wall entries should be corrected so water doesn't sit against the insulation. If you hear vibration or see tubing touching siding, conduit, or framing, fix it. Pinhole leaks often look mysterious from a distance, but up close they usually trace back to movement, contamination, or material weakness that could have been spotted earlier.

What is the total cost comparison between pre-insulated line sets and field-wrapped installation?

Pre-insulated line sets usually cost more upfront but often reduce total installed cost by eliminating 45 to 60 minutes of wrapping labor, reducing insulation errors, and lowering callback risk. In many real jobs, that labor savings alone offsets much of the higher material cost.

Field-wrapped tubing can still work, especially on custom commercial layouts, but it introduces more labor variables. The installer has to wrap, tape, seal seams, and protect transitions, and every one of those steps can fail if rushed. On typical residential jobs, saving **47 minutes** of labor can mean roughly **\$75 to \$120** back depending on crew rate. Then add the avoided cost of condensation damage, insulation separation, or a return trip to rewrap exposed sections. That's why many contractors prefer factory-insulated assemblies on repeat residential work: cleaner installs, more consistent vapor protection, and fewer surprises after startup. Upfront material cost matters, but total job cost is what actually hits your margin.

Conclusion

Measuring a **line set for AC unit** installation isn't complicated.

But it is unforgiving.

You measure the real route.



Industry Leading Mini-Split Copper Line Set

Enjoy
**FACTORY
DIRECT
Savings**

Order Now &
Upgrade Your
HVAC System

Unmatched
Industry Expertise

Fast & Reliable
Shipping

Exclusive
Trade Pricing

Dedicated
Customer Support

You add what the job actually needs. You verify size, length, access, and exposure before you cut or order. And you stop treating the tubing like an accessory to the equipment.

That's the lesson Leandro took from one bad insulation failure and one much better install process. Once he started measuring for route reality instead of visual distance, his installs cleaned up, his ordering got easier, and the line-related callbacks stopped showing up.

If you remember one thing, make it this: the right **ac unit line set** length is not the shortest number you can justify. It's the number that lets the system run correctly, lets you connect it cleanly, and lets you walk away knowing you won't be back for free.

Author Bio

Nadia Mercer is a mechanical contractor with **13 years** of experience coordinating HVAC and hydronic installations across western Pennsylvania. She works primarily on mixed-use retrofit projects in the Pittsburgh region and holds a statewide boiler and pressure systems inspector credential earned after leading commissioning on a 96-unit multifamily renovation.