

Termites do not announce themselves with fanfare. They work in quiet, humid darkness, softening joists, hollowing sill plates, and surfacing only when a baseboard crumbles under a fingertip. By the time a homeowner searches for termite repair near me, there is usually real damage to address. Choosing the right professional is not just about patching what you can see. It is about stopping the infestation, restoring strength to the structure, and protecting your home from a repeat performance.

This guide comes from years of walking crawlspaces, reading grain patterns with a flashlight and awl, coordinating with pest teams, and explaining the plan to anxious homeowners. If you want clarity on termite wood repair and how to select capable termite repair services, you are in the right place.

What termite repair really includes

Termites do not pick spots at random. They chase moisture and warmth. That is why damage clusters in sill plates above damp foundation walls, floor joists near leaky bathrooms, subfloors under vinyl that has trapped steam, and attic members where a bathroom vent dumps humid air. Structural members like beams and posts take a beating when termites find them early in a home's life or when a long drip from a hose bib keeps a foundation corner wet.

Termite structural repair goes beyond cutting and plugging a soft area. The carpenter must restore load paths. If termites reduce a 2 x 10 floor joist to a brittle shell, the repair needs to replace or supplement the missing capacity in a way that ties back into the existing framing. For major components, that usually means sistering new lumber, installing engineered LVL members, or swapping out sections while the structure is temporarily shored. For minor areas, consolidating the remaining fibers with structural epoxy and adding a doubler may be appropriate. Good termite damage restoration considers more than wood. It touches the finishes that wrap that wood: drywall, trim, flooring, tile, paint.

I have seen houses that looked tidy from the living room only to reveal sponge-like rim joists in the crawlspace. And I have opened finished basements where termite wall repair required peeling back paneling, cutting studs, re-insulating, then rebuilding the whole corner. The real cost of termite damage repair often lives in the time and care it takes to open and close the envelope respectfully.

Exterminate first, then rebuild

If you repair before the bugs are dead, you are building a buffet. The rule is simple. Get a licensed pest control operator to identify the species, outline a treatment plan, and provide documentation. In many states, you will receive a Wood Destroying Organism inspection report before a home sale or refinancing. Even outside a transaction, ask for a written report and keep it.

Expect localized chemical treatment of galleries, bait stations in the soil, or full soil treatment around the foundation. Drywood termites may require localized injections, heat, or in rare cases tenting. Subterranean termites respond well to soil treatments and baiting. After treatment, your contractor can schedule termite drywall repair after termite treatment, and begin the structural work with confidence.

There is a gray area when emergency shoring is necessary. If a beam is visibly sagging, a pro may set temporary posts and a header on day one to stop further deflection, even before the termite crew arrives. That is stabilization, not full repair, and it keeps occupants safe while the wrench turns on the pest side.

Where damage hides and how pros find it

Termites travel in narrow, protected routes. Pros learn to read these routes like trail markers. On foundations, mud tubes climb like dry rivers where termites commute between soil and sill plates. In crawlspaces, the tell is often pinhole frass, a hollow thud when tapping a joist, or a screwdriver that sinks into what looks like sound wood. In attics, look for blistered sheathing above a misdirected bath fan or attic wood repair needs around poorly flashed penetrations.

Common hot spots and related repair types include:

- Sill plates that crumble atop a damp foundation wall. Termite sill plate repair typically involves jacking the rim slightly, sliding in a new pressure treated plate or borate treated alternative, and re-anchoring to the concrete with proper bolts or epoxy-set anchors.
- Floor joists with tunnels near bathrooms or kitchens. Termite floor joist repair may be a full sister with a matching species and grade, glued and bolted, or a partial scab if only the end is affected.
- Beams that have lost a chunk of their bearing area. Termite beam repair ranges from engineered plating with steel or LVL to complete beam replacement with temporary shoring. When long beams pass over posts, bearing checks matter as much as midspan strength.
- Subfloor with soft spots at exterior walls or under old vinyl. Termite subfloor repair often means cutting back to the center of joists and replacing sheets, then tying into existing flooring without telegraphing a seam.
- Wall studs behind baseboards that flake at a touch. Termite wall repair may involve selective stud replacement, blocking, and re-sheathing, followed by drywall and trim work.

A skilled eye makes a difference. I have watched new inspectors miss a line of mud the width of a shoelace on a block wall, then seen a veteran crawl the same bay and point straight to a sill end that had turned to cork. If you can, ask to join the inspection. You will learn how to read your own house.

Materials that stand up and those that do not

For structural termite repair near me searches, you will see a mix of opinions on materials. Here is what holds up in practice.

Pressure treated lumber stands up well where wood contacts masonry or sits in damp pockets. It resists rot and gives termites fewer reasons to return. Borate treated lumber offers better termite resistance with fewer corrosion issues on hardware, but it is harder to source in some regions. When replacing only portions of members, carpenters use structural screws or through bolts to ensure composite action, not just nails.

Epoxy consolidants and fillers have a place. If a historical sill has a localized check and the load is light, stabilizing the remaining fibers with a quality epoxy system can work. I do not use epoxies to rebuild heavily loaded members, especially not as a substitute for lost section in beams or major joists. Wood is cheap compared [Vanguard pre-purchase inspections Watsonville](#) to a call back.

For beams, LVLs provide predictable strength and good bearing. If you are marrying an LVL to a dimensional lumber member, watch depth and camber so the pair shares load after fastening.

On finishes, moisture tolerant backers and appropriate membranes are essential where water contributed to the original issue. There is no sense reinstalling a standard paper faced drywall in a bathroom that lacks a proper fan. Moisture control is termite prevention by another name.

Who you actually need on the team

Resist the idea that one company does everything at the same level. Termite repair services tend to work best in pairs. You want a licensed pest control operator to kill the colony and set up monitoring, then a carpenter or general contractor to repair and rebuild. For significant structural termite repair near me, an engineer's letter and stamped repair detail is money well spent. I bring in engineers whenever a load bearing wall is involved, a main beam has visible section loss, or a foundation shows deflection along with termite damage. The fee often sits in the 500 to 1,500 dollar range and saves debate with building officials and insurers later.



Permits vary by jurisdiction, but here is a rough guide. Replacing finishes and non structural trim rarely requires a permit. Repairing or replacing structural members, altering headers, or changing beams usually does. In flood zones and historic districts, even minor work may require review. A contractor comfortable with local inspectors will handle this without drama.

Insurance seldom covers termite damage. Termites are classified as maintenance. A few policies offer limited endorsements, but do not count on a claim to fund major work. Lenders, on the other hand, often require clearance letters before closing. That is another reason to keep treatment records and repair photos.

A simple checklist for vetting a local termite damage contractor

- Proof of licensing, general liability insurance, and workers comp, with certificates sent from the insurer.
- Photo documentation in estimates, with notes that show they actually crawled the space and opened a test area.
- Experience with your house type, such as pier and beam, slab on grade with interior bearing, or balloon framing in older homes.
- Plan for temporary shoring, dust control, and occupant safety, especially if children or pets are in the home.
- Written warranty that distinguishes between workmanship on repairs and the pest company's retreatment warranty.

Ask for two or three references from recent, similar jobs. Not a deck build from five years ago, but a termite framing repair in a crawlspace last fall or a termite beam repair in a basement this spring.

Building apples to apples estimates

Most bad experiences start with vague scopes. You want line items. Demo and disposal matter. If a contractor writes repair termite damage to house as a single sentence, push for details. Which joists are included, how will

they access the area, what is the plan for shoring, and how will they protect adjacent finishes?

A thorough termite damage repair estimate for a wood framed home usually includes:

- Access and protection. This covers floor protection, containment plastic, negative air if needed, and safe entry to crawlspace or attic. If your only crawlspace hatch is a tiny closet opening, someone needs to enlarge it and put it back.
- Temporary shoring. Where members are compromised, I expect screw jacks, cribbing, and a layout that transfers load. Height adjustments are measured in small turns to avoid cracking finishes upstairs.
- Removal of affected members. Carpenters do not just lop off rotten ends. They backcut to good fibers, then prep the surface for a clean scarf or butt joint where needed.
- Replacement or sistering with clear specs. Length of sisters, fastening pattern, adhesive use, and species or engineered alternative all belong in writing.
- Treatment of exposed areas and debris handling. After demo, many pros apply a borate treatment to adjacent wood and vacuum fine debris. Cellulose left in a crawlspace is an invitation.
- Finish restoration. Drywall, trim, paint, flooring patches, and any tile or cabinetry that must be disturbed. The best contractors tell you exactly what they will patch and what will need a specialist.

Ask for a payment schedule tied to milestones, not just dates. A fair plan might place a small deposit to cover materials, a progress payment after shoring and demo, another after structural repairs pass inspection, and the balance after finishes are complete. Clarify change order policy for hidden damage beyond the visible scope.

What fair pricing often looks like

Prices swing by region, access, and finish level. Crawlspace height, for example, can double labor if workers must belly crawl with lumber. Still, some defensible ranges help you sanity check quotes.

- Termite sill plate repair typically runs 60 to 120 dollars per linear foot when accessible from a crawlspace, including new pressure treated plate, anchors, sill sealer, and labor. Tight access or masonry prep can push this higher.
- Termite floor joist repair by sistering often falls between 350 and 800 dollars per joist, depending on length, fasteners, and access. Full joist replacement costs more, especially if bearing pockets need chipping or new hangers.
- Termite beam repair varies widely. Plating a small section with LVL and bolts may be 1,500 to 3,000 dollars. Full replacement with temporary shoring and multiple posts can reach 4,000 to 10,000 dollars or more, particularly if finishes or utilities complicate the work.
- Termite subfloor repair is usually priced per sheet. Expect 300 to 650 dollars per 4 x 8 sheet installed in a crawlspace, more if plumbing fixtures or tile must be removed and reset.
- Termite wall repair with stud replacement in a finished area depends on finishes. Replacing a few studs, re-insulating, new drywall, base, and paint in a corner can land between 900 and 2,500 dollars. Termite drywall repair after termite treatment alone is far less, but usually not the whole story.

Combine multiple scopes and the price does not scale linearly. Mobilization, containment, and supervision costs spread across tasks, so bundled work may come in lower per item than doing each piecemeal over several months.

Red flags and green lights

If a contractor minimizes structural loss you can see with your own eyes, keep looking. So does the pro who proposes epoxy as a miracle cure for a beam that has lost half its depth, or suggests skipping shoring to save time. Another red flag is a lack of communication with the pest company. Repair and treatment are two halves of the same circle.

Green lights show up in small behaviors. A contractor who carries a moisture meter and uses it. One who marks each repair point with spray chalk, takes photos, and sits with you to explain the sequence. I like seeing a basic load path sketch, even if it is hand drawn on graph paper. It tells me the person has thought about how weight moves through your house.

A five step path from first call to finished repair

- Confirm active or recent infestation status with a licensed pest control company and schedule treatment with a written report.
- Invite two or three repair contractors to inspect, photograph, and open a small test area where finishes allow.
- Select a contractor who can coordinate with the pest pro, secure permits if needed, and provide a clear plan for shoring and sequencing.
- Complete structural repairs first, then close finishes in a clean work area with good dust control. If flooring is being patched, do it before final paint.
- Set up prevention, including moisture corrections and a retreatment or monitoring plan with the pest company, then calendar an annual inspection.

Those steps apply whether you are seeking structural termite repair near me for a beam in a basement or local termite damage repair for a small crawlspace sill.

Moisture control is not optional

Every successful repair includes moisture fixes. Termites need water. Lower the moisture, lower the risk. Start outside. Correct grade so water moves away from the foundation. Add or repair gutters and downspouts that carry water at least five feet from [Vanguard termite inspections watsonville](#) the house. In crawlspaces, lay down a continuous vapor barrier, seal overlaps, and consider conditioning or vent adjustments based on your climate. Remove all scrap wood and cardboard. In bathrooms, vent to the exterior and run the fan long enough to clear humidity after showers.

Inside, fix small drips promptly. I once traced recurring termites on a rim joist to a refrigerator ice maker line that wept barely a teaspoon a day. Over a year, that fed a colony and softened ten feet of subfloor.

A short case study from the crawl

A family called about spongy floors near their back door and an online search for termite damage repair near me staring back from their phone. The house sat on a low crawlspace with vents half buried in mulch. The pest inspector found active subterranean termites and mud tubes rising to the sill plate. Treatment went in the same week.

Our repair plan focused on a 16 foot sill run and six floor joists that had lost 30 to 60 percent of their section over the last few feet to the rim. Access was tight, so we cut a larger hatch in a closet and built a temporary ramp. We shored the area with two screw jacks and a 4 x 6 header, raising only enough to take weight off the damaged members.

We replaced the sill plate with borate treated lumber, set on sill sealer with epoxy anchors into the block. For the joists, we sistered full length 2 x 10s with construction adhesive and a staggered pattern of structural screws, then installed new hangers at the ledger. Subfloor patches covered two 2 x 4 foot sections that crumbled under foot pressure. We sprayed a borate solution on adjacent framing and vacuumed all friable debris.

Inside, we patched drywall where exploratory holes were cut, reset baseboard, and blended paint. Outside, we regraded mulch away from the vents and extended two downspouts. The family spent four nights at a relative's place during the noisiest portion. The final bill landed at 8,700 dollars, including pest treatment. A year later, the floors are firm, moisture readings are lower, and monitoring shows no new activity.

What homeowners often get wrong

Painting over damage does not fix it. I scrape more fresh paint than I care to admit to reach soft wood behind. Another common mistake is skipping treatment because there are no visible bugs. Termites love the parts of your home you rarely see. If wood sounds hollow or you find frass that looks like ground pepper, call a pro.

Epoxy has its place, but not as a magic wand. Use it to consolidate light damage in non critical members. Use wood and steel to restore structure. Lastly, many folks assume a handyman can handle termite framing repair because wood is wood. Structural work benefits from proper shoring, fastening patterns, and a feel for how loads transfer. You want a wood repair contractor termite damage near me result that does not need a second pass.

Tying it all together for your search

Typing termite repair near me or termite damage repair near me into a search bar brings up a mix of pest firms, general contractors, and one man shops. Start with the pest company to stop the cause. Bring in a contractor who is comfortable with structure, not just finishes. Use the checklist to filter candidates. Ask for clear scopes, photos, and line item pricing. Expect a thoughtful sequence that begins with shoring, moves through replacement or sistering, then finishes with careful restoration.

The right team will make your home stronger than it was before the first bug arrived. With smart moisture control, a retreatment warranty, and an annual inspection on your calendar, you will likely never need to search for a termite damage contractor near me again.

If you are standing above a soft floor, reading this on your phone, you are not alone. Real pros do this work every week. They crawl, they shore, they rebuild, and they leave quiet strength behind. That is what you are buying, not just new wood.